HIDE ASSEMBLY INSTRUCTION







7. Put the bar on back door





- 1. Put the boxes on flat floor
- 2. Get out the parts from the boxes
- 3. Open the bottom across







6. Put the top part on the front door



- 10. Remove the cover for door plates 11. Tight 16 sets M6 screws, washes and nuts for 4 door plates

- - 8. 8pcs M5 screws and 8pcs M5 nuts for assembly



12. Put the cover and lock 4 sets screws

- - 9. Lock 4 sets screws on bottom



13. Put the plastic garbage into HIDE